

DTC	P0441	Evaporative Emission Control System Incorrect Purge Flow
-----	-------	--

DTC	P0446	Evaporative Emission Control System Vent Control Circuit
-----	-------	--


DTC	P2418	Evaporative Emission System Valve Control Circuit/Open
-----	-------	--

CIRCUIT DESCRIPTION


The vapor pressure sensor, canister closed valve (CCV), and pressure switching valve are used to detect abnormalities in the evaporative emission control system.

The ECM decides whether there is an abnormality in the evaporative emission control system based on the vapor pressure sensor signal.

DTCs P0441, P0446 and P2418 are recorded by the ECM when evaporative emissions leak from the components within the dotted line in Fig. 1 below, or when there is a malfunction in either the EVAP VSV, the pressure switching valve, or in the vapor pressure sensor itself.



2007/04/17



DTC No.	DTC Detecting Condition	Trouble Area
P0441	Pressure in charcoal canister and fuel tank does not drop during purge control (2 trip detection logic)	<ul style="list-style-type: none"> Vacuum hose cracked, holed, blocked, damaged or disconnected ((1), (2), (3), (4), (5), (6), (7), (8) and (9) in Fig. 1) Fuel tank cap incorrectly installed Fuel tank cap cracked or damaged Open or short in vapor pressure sensor circuit Vapor pressure sensor Open or short in VSV circuit for EVAP EVAP VSV Open or short in VSV circuit for CCV CCV Open or short in VSV circuit for pressure switching valve Pressure switching valve Fuel tank cracked, holed or damaged Charcoal canister cracked, holed or damaged ECM
	During purge cut-off, pressure is very low compared with atmospheric pressure (2 trip detection logic)	
P0446	No rising in the fuel tank pressure when commanding the CCV open after an EVAP leak test	
	A high negative pressure (vacuum) does not occur in the system when commanding the EVAP VSV open and CCV closed with the pressure switching valve open	
P2418	No changing in the fuel tank pressure when commanding the pressure switching valve closed for the check after the EVAP leak test	
	A high negative pressure (vacuum) does not occur in the system when commanding the EVAP VSV open and CCV closed with the pressure switching valve open	

HINT:

Typical DTC output of each trouble part

Trouble part	Typical DTC output (*1)
Small Leak	P0442 and/or P0456
Medium Leak (ex: Vacuum hose loose)	P0455
Large Leak (ex: Fuel tank cap loose)	P0441, P0446, P0455 and P2418
EVAP VSV	Open Malfunction Close Malfunction
	P0441, P0446, P0455 and P2418 P0441, P0446, P0455 and P2418
CCV	Open Malfunction Close Malfunction
	P0446 P2418
Pressure Switching Valve	Open Malfunction Close Malfunction
	P2418

(*1) ECM may output some other DTC combinations.

2007/04/17

MONITOR DESCRIPTION

P0441

The ECM checks for a stuck closed malfunction in the EVAP VSV by commanding it to open. If there is a malfunction detected in the evaporative emission (EVAP) VSV, the canister closed valve (CCV) and the VSV for bypass valve; the ECM will illuminate the MIL and set a DTC. This portion of the EVAP diagnosis checks the following EVAP system functions:

- (a) CCV stuck closed.

The ECM checks for a CCV "stuck closed" malfunction by commanding the CCV to open after an EVAP leak test. If the fuel tank pressure does not rise (lose vacuum), the ECM determines that the CCV is stuck closed. The ECM will turn on the MIL and a DTC is set.

- (b) EVAP VSV (Purge line to intake manifold) stuck closed.

The ECM checks for a stuck closed malfunction in the EVAP VSV by commanding it to open with the EVAP VSV closed. If a high negative pressure does not develop in the fuel tank, the ECM determines that the EVAP VSV remains closed. The ECM turns on the MIL and a DTC is set.

P2418

- (a) pressure switching valve stuck open.

The ECM checks for a pressure switching valve "stuck open" malfunction by commanding the pressure switching valve to close after an EVAP leak test. If the fuel tank pressure does not change, the ECM determines that the pressure switching valve is malfunctioning. The ECM will turn on the MIL and a DTC is set.

- And when EVAP VSV stuck closed malfunction is detected, the ECM also stores this DTC (P2418). When EVAP VSV (Purge line to intake manifold) stuck closed is detected, the pressure switching valve malfunction DTC is also stored.

2007/04/17

MONITOR STRATEGY

DTCs	P0441	EVAP VSV malfunction
	P0446	Canister close valve stuck closed Pressure switching valve malfunction EVAP VSV malfunction
	P2418	Pressure switching valve malfunction
Required sensors/components	Mainsensors/components	Vapor pressure sensor
	Relatedsensors/components	Engine coolant temperature sensor, Intake air temperature sensor, Vehicle speed sensor
Frequency of operation	Once per drive cycle	
Duration	P0441 : 90 sec. P0446 : 10 sec. P2418 : 10 sec.	
MIL operation	2 drive cycles	
Sequence of operation	None	

TYPICAL ENABLING CONDITIONS

Item	Criteria	
	Minimum	Maximum
The monitor will run whenever the following DTCs are not present	See "List of disable a monitor" (on page DI-337)	
The same as that for DTC P0442		

TYPICAL MALFUNCTION THRESHOLDS

P0441

Detection Criteria	Threshold
Either the following condition is met:	A or B
A. Following conditions are met:	(a) and (b)
(a) Fuel tank pressure at the vacuum introduction start	-1.6 kPa (-12 mmHg, -0.47 in.Hg) or more
(b) Difference between the fuel tank pressure at the vacuum introduction start and completion	Less than 0.9 kPa (7 mmHg, 0.27 in.Hg)
B. Following conditions are met:	(a) and (b)
(a) Difference between "minimum" fuel tank pressure before the leak check and the fuel tank pressure at 14 sec. after the leak check	0.5 kPa or more (3.5 mmHg, 0.15 in.Hg)
(b) Fuel tank pressure at 14 sec. after the leak check	Less than -3.7 kPa (-28 mmHg, -1.1 in.Hg)


P0446

Detection Criteria	Threshold
Case 1: CCV stuck closed	
Fuel tank pressure when the CCV is opened after an EVAP leak check	Not changing
Case 2: EVAP VSV stuck closed	
Fuel tank pressure after the EVAP VSV is opened and manual vacuum is introduced to the fuel tank	

2007/04/17

VSV FOR EVAPORATIVE EMISSION (EVAP) COMPONENTS

2007/04/17



INSPECTION


1. REMOVE V-BANK COVER
2. REMOVE VSV

3. INSPECT VSV

- (a) Inspect the VSV for open circuit.
Using an ohmmeter, check that there is continuity between the terminals.


Resistance: 30 – 34 Ω at 20°C (68°F)

If there is no continuity, replace the VSV.




- (b) Inspect the VSV for ground.
Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.




- (c) Inspect the VSV operation.
 - (1) Check that air does not flow from ports E to F.



- (2) Apply battery positive voltage across the terminals.
- (3) Check that air flows from ports E to F.


If operation is not as specified, replace the VSV.

4. REINSTALL VSV
5. REINSTALL V-BANK COVER



2007/04/17

2007/04/17



SF-60

INSPECTION

REMOVE V-BANK COVER

1. REMOVE INTAKE AIR CONNECTOR PIPE
2. DISCONNECT THROTTLE BODY FROM INTAKE MANIFOLDS (See page SF-37)
3. REMOVE UPPER AND LOWER INTAKE MANIFOLDS ASSEMBLY (See page EM-36)
4. REMOVE VSV
5. REMOVE VSV



2007/04/17

INSPECT VSV

- (a) Inspect the VSV for open circuit.
Using an ohmmeter, check that there is continuity between each terminals.

Resistance: 33 – 39 Ω at 20°C (68°F)

If there is no continuity, replace the VSV.




- (b) Inspect the VSV for ground.

Using an ohmmeter, check that there is no continuity between each terminal and the body.


If there is continuity, replace the VSV.

Inspect the VSV operation.

- (1) Check that air flows from port E to the filter.



BG0276




BG0277

- (2) Apply battery positive voltage across the terminals.
(3) Check that air flows from port E to F.
If operation is not as specified, replace the VSV.


7. REINSTALL VSV
8. REINSTALL UPPER AND LOWER INTAKE MANIFOLDS ASSEMBLY (See page EM-60)
9. REINSTALL THROTTLE BODY TO INTAKE MANIFOLDS (See page SF-40)
10. REINSTALL INTAKE AIR CONNECTOR PIPE
11. REINSTALL V-BANK COVER

VSV FOR CANISTER CLOSED VALVE (CCV) COMPONENTS



2007/04/17

VSV FOR PRESSURE SWITCHING VALVE COMPONENTS



N · m (kgf · cm, ft · lbf) : Specified torque

2007/04/17

INSPECTION

1. DISCONNECT BODY

/04

2. REMOVE VSW

2007/04/17

3. INSPECT VSW


- (a) Inspect the terminals. Using an ohmmeter, check that there is continuity between the terminals.

If there is no continuity, replace the v.v.


B01273

200

(c) Inspect the VSV operation.



800793



CONTINUOUS


(2) Apply battery positive voltage across the terminals
 (3) Check that air flows from ports E to F.

REINSTALL VSV
REINSTALL CHARCOAL CANISTER ASSEMBLY


INSPECTION

REMOVE VSV

1.




B09580



B09581



B09582



B09583

2007/04/17

INSPECT VSV

- (a) Inspect the VSV for open circuit.
Using an ohmmeter, check that there is continuity between terminals.

Resistance: $24 - 30 \Omega$ at 20°C (68°F)

If there is no continuity, replace the VSV.

- (b) Inspect the VSV for ground.
Check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.

- (c) Inspect the VSV operation.
(1) Check that air flows from port B to A.

- (2) Apply battery positive voltage across the terminals.
(3) Check that air flows with difficulty from port B to A.
If operation is not as specified, replace the VSV.

3. REINSTALL VSV